

VESSEL SANDING ARBOUR





- Engineer version custom made
- Starts as 10mm x 100mm Coach bolt
- Head turned back so as not to damage wood
- Reduction also enables sanding lower in vessel
- End of bolt turned down to 3/8" diameter to fit drill



- Mirka Abranet abrasive
- 80 / 120 Grit ?
- Plumbers rubber washers



- Silverline product "Drill Arbour"
- Smaller and lighter



- Assemble by:
- Cut 24 sheets of Abranet in half lengthwise
- Punch a 12mm hole in the middle of each sheet
- Insert onto coach bolt drive by laying four sheets together
- Insert a rubber washer between sets of four
- Insert the next four sheets at 90 degrees to the previous set
- Continue until all 48 sheets re used.
- Lock in place with the nut



- Finished assembled sanding pad
- Drive via flexible drive
- Hold drill in 42mm grip (made from side handle grip)
- Drilled and tapped into bar held in tool post for convenience
- Flexible drive requires two handed operation